

TAPE SCISSORS

20.807.889.00

Installation Instructions

BANDSCHERE

20.807.889.00

Einbauanleitung

Prepared and edited by:
Studer Professional Audio AG
Technical Documentation
Althardstrasse 30
CH-8105 Regensdorf – Switzerland

Copyright by Studer Professional Audio AG
Printed in Switzerland
Order no. 10.27.3280 (Ed. 1098)

Subject to change

Studer is a registered trade mark of Studer Professional Audio AG, Regensdorf

INSTALLATION INSTRUCTIONS TO OPTION 20.807.889.00

TAPE SCISSORS for machines without TC head

Modification-Kit

consisting of:

1	Pair of tape scissors, incl. fixing screw	1.020.889.81
1	End bracket	1.050.340.06
1	Instruction sheet	

TAPE SCISSORS for machines with TC head

Modification-Kit

consisting of:

1	Pair of tape scissors, incl. fixing screw	1.020.889.81
1	End bracket (not needed for this version)	1.050.340.06
1	Plastic cover	
1	Instruction sheet	

Required tools

- 1 Allen screwdriver 2,5mm
- 1 Allen screwdriver 3mm
- 1 Screwdriver for recessed-head screws No. 0

Installation

- Unscrew the pinch roller and the headblock.
- Unscrew the head shield and remove the plastic blanking plug (on machines without TC head) or the left-hand metal plug (machines with TC head).
- Remove the end bracket.
- On the TC headblock remove the plastic cover and replace it with the cover included in the kit.
- Place the tape scissors on the headblock chassis (align the locating pin with the drill hole), press it in, and tighten the screw. Do not cant the tape scissors. They must make full contact along the entire base surface.
- Install the end bracket (only for headblocks without TC head).
- Install the head shield and the headblock as well as the pinch roller in the machine.

Functional check

When the tape scissors are actuated the push button should move without binding. If necessary, loosen and adjust the head cover.

EINBAUANLEITUNG ZU OPTION 20.807.889.00

BANDSCHERE für Geräte ohne TC-Kopf

Nachrüst-Kit

enthaltend:

1	Bandschere kpl. mit Befestigungsschraube	1.020.889.81
1	Abschlusswinkel	1.050.340.06
1	Einbauanleitung	

BANDSCHERE für Geräte mit TC-Kopf

Nachrüst-Kit

enthaltend:

1	Bandschere kpl. mit Befestigungsschraube	1.020.889.81
1	Abschlusswinkel (wird für diese Version nicht benötigt)	1.050.340.06
1	Plastik Abdeckung	
1	Einbauanleitung	

Benötigtes Werkzeug

- 1 Innensechskant Schraubendreher 2,5mm
- 1 Innensechskant Schraubendreher 3mm
- 1 Kreuzschlitz Schraubendreher Nr. 0

Einbau

- Andruckrolle und Kopfträger abschrauben.
- Kopfabdeckung abschrauben und Plastik-Blindstopfen (bei Geräten ohne TC-Kopf) oder linken Metallstopfen (bei Geräten mit TC-Kopf) entfernen.
- Abschlusswinkel demontieren.
- Bei TC-Kopfträger Plastikabdeckung entfernen und durch im Kit vorhandene ersetzen.
- Bandschere auf Kopfträgerchassis aufsetzen (Pass-Stift auf vorgesehene Bohrung ausrichten), einpressen und festschrauben. Bandschere nicht verkanten. Sie muss mit der ganzen Basisfläche satt aufliegen.
- Abschlusswinkel (nur für Kopfträger ohne TC-Kopf) montieren.
- Kopfabdeckung montieren und Kopfträger sowie Andruckrolle im Gerät einbauen.

Funktionskontrolle

Beim Betätigen der Bandschere muss sich der Druckknopf frei bewegen. Wenn nötig Kopfabdeckung lösen und justieren.