

How to get into bios-setup

BIOS: when keyboardlight comes on, press and hold F2

Revision #3

Created 2026-04-01 17:14:07 CEST by Philip

Updated 2026-04-13 19:24:56 CEST by Philip