

Speedtouch commands

show timeservers

```
sntp list
```

show dns servers

```
dns server route list  
dns server route add dns=1.1.1.1 metric=5
```

add route

```
ip rtadd  
dst=0.0.0.0  
dstmask=255.255.255.255  
label=  
gateway=192.168.1.254  
intf=  
srcintf  
metric=0
```

ip rtadd

Add a route to the routing table. SYNTAX:

```
ip rtadd  
dst =  
[dstmsk = <ip-mask(dotted or cidr)>]  
[label = ]  
[gateway = ]  
[intf = ]  
[srcintf = ]  
[metric = <number{0-255}>]
```

Revision #3

Created 2026-04-13 18:29:06 CEST by Philip

Updated 2026-04-13 19:31:34 CEST by Philip