

Dig<u>AS</u> DigaStudio





# **Content**

1	Ove	rview	. 3		
1	.1 Ph	nilosophy	3		
1	.2 Ho	ousing	4		
-	1.2.1	Control pad			
	1.2.2	Interface unit	4		
2	Fund	ctionality	. 5		
່າ	1 Δι	idio input	5		
2	1 70 2 Ch	annal functions			
2	.Z UI	Course coloction / channel accignment	0		
	2.2.1	Juniter / clipping display	0		
	2.2.2	Enniter / Cipping display	0		
	2.2.3	Channel Mode	0		
	2.2.5	Inserts / effects	7		
	2.2.6	Fader / level meter	7		
	2.2.7	Mute button and talk-back	7		
2	.3 Su	Immina busses	8		
2	.4 Ou	Jtputs	8		
	2.4.1	Monitor matrix	9		
2	.5 GF	PI / external level meters	9		
2	.6 Die	gaStudio Pro	9		
	2.6.1	Channel functions	9		
	2.6.2	Microphone inputs	10		
	2.6.3	Digital audio inputs	10		
	2.6.4	Digital audio outputs	10		
3	Edit	Controller	10		
Λ		control	11		
-			• •		
5	j Accessories12				
6	6 Technical Data13				

# All of the specifications contained in this document can change without notice Status as of: 14.04.99













# **1** Overview

**DigaStudio** is an audio and control interface for users of PC audio workstations who do not have a studio environment available. The product is designed for normal office environments and users who are not specifically trained as audio technicians.

DigaStudio consists of an interface and signal-processing module and a separate flat control-pad. The control-pad is connected by means of a single cable to the interface module, to which all audio and control lines are connected. It is designed to avoid looking like a technician's workbench with masses of cable on the desk. The entire system provides an integrated studio with user-friendly interface at "your" workstation, containing the following functionality:

- Input matrix: connection and selection of a variety of audio sources
- Mixer: typical mixing and editing functionality
- Edit Controller: control panel for the editing software

The following typical tasks are possible:

- Recording from microphone or any other connected source
- Recording of interviews with multiple partners
- Recording of telephone interviews (via telephone or ISDN codec)
- Production of audio clips with simple mixing of pre-produced elements and live sources
- Playback of live events with microphone and PC recording or other sources
- Transfer of edited clips to main studio or between various media

The product is available in two versions: **DigaStudio** und **DigaStudio Pro**. The additional functions of the pro version are explained in section *2.6 DigaStudio Pro*.

### 1.1 Philosophy

- Ease-of-use
- Simple implementation, therefore mainly analogue inputs and outputs
- Internal digital signal processing
- High number of external devices connectable through various audio connectors
- Very high input dynamic range (24-bit A/D) so that overdrive problems are not encountered with unskilled users

Use of the system is divided into those important operations which are accessed directly via the control pad, and those functions which can only be accessed by means of software on the PC. The latest settings are stored in the processing unit so that it can perform its basic functions without being connected to the PC.

**DigaStudio**'s parameters can be made user-specific by means of the PC, so that user-profiles can move with the user to various workstations. Specific settings, such as the filter parameters, can be stored on a per-user basis and then activated in the signal processing unit as the user logs-in.













# 1.2 Housing

**DigaStudio** consists of a 19" (2HE) interface and signal processing unit and a flat control pad. The control pad is connected to the interface unit by means of a single cable. The length of the cable is unrestricted (with respect to typical studio environments).

#### 1.2.1 Control pad

- Flat desktop case
- A single-cable connection to the interface unit
- Control elements for the functions described below
- Pre-drilled for optional gooseneck microphone



Control Pad

#### 1.2.2 Interface unit

- 19" (2HE)
- Power-supply (internal) for all supply voltages w/ power switch on the front panel
- Connectors for all incoming and outgoing audio and control signals on the rear panel



Rear view of interface unit













# 2 Functionality

### 2.1 Audio input

The control pad contains an input matrix which allows the connection of the following sources:

- 2 x MIC (microphone)
- 2 x LINE
- 1 x TV / Tuner
- 1 x AV / AUX
- 1 x AWS (PCX card)
- 1 x TEL (external telephone hybrid)
- 1 x ISDN (external ISDN codec)
- 1 x INSERT

All inputs have adjustable input-level controllers which can be controlled via the PC software so that the signal level can be adjusted individually prior to the A/D convertion.

Both **MIC** inputs (MIC1 / MIC2) are symmetrical mono inputs using XLR connectors with input transformer. 48V phantom power is switchable. Input sensitivity can be adjusted within 0,5 dB steps from -20..-80 dBu.

Both **LINE** inputs are configured as stereo sources and can handle symmetrical and asymmetrical signals. There are 2 XLR jacks for the symmetrical configuration and 2 cinch jacks each for the asymmetrical. The symmetrical and asymmetrical inputs are passively mixed but are actively decoupled to allow concurrent use.

TV / TUNER and AV / AUX inputs are each configured as stereo sources, each with 2 XLR connectors.

The audio workstation input (**AWS / PCX**) is also configured as a symmetrical stereo source (analog), but uses a 15-pin sub-D connector for directly connecting to a PCX card (including return path to audio input of PCX board).

The **TELEPHONE** input is for connecting an analog telephone hybrid and is configured as a mono source. It uses a 15pin sub-D connector and contains both the return channel and external control signal for activation.

For connecting an **ISDN** codec a separate symmetrical stereo input is provided, which also uses a sub-D connector connector (including return signal and control signal as well).

The **INSERT** input is provided so that effects devices or signal processors (e.g. voice processors) can be switched in. It is configured as a symmetrical stereo input with a 15-pin sub-D connector. The connector also contains the necessary INSERT SEND output.

All of the symmetrical inputs are electronically balanced, with the exception of the two transformer symmetrical microphone inputs. The input sensitivity can be set in 0.5 dB steps between +24..-10 dBu.













### 2.2 Channel functions

The basic version of the DigaStudio contains 3 mixing channels, which are described below.

#### 2.2.1 Source selection / channel assignment

Channel 1 can be assigned to MIC1 or MIC2, whereas channels 2 and 3 can be assigned to any source. There are 8 source selection buttons associated with channel paths 2 and 3. The channel selection is "1 from N", so that one source can only be assigned to one channel. The currently selected input source is illuminated. The assignment of the input sources to the output buttons can be freely selected. The labels for the input selection buttons can be customized by means of a special adhesive foil.



#### 2.2.2 Limiter / clipping display

Each channel has its own adjustable limiter which can be switched on or off by means of an illuminated button. The limiter can either be assigned to the individual channels or the sums. The configuration is controlled from the PC software.

To prevent the input A/D converter being over-driven a clipping display is provided (special function within the level bar-graph).

#### 2.2.3 Equalizer / filter

Each channel has its own 3-band equalizer with the following characteristics:

- low-band shelf-type filter
- parametric mid-frequencies
- high-band shelf-type filter

The microphone inputs have additional switchable high-pass filters available.

The equalizer and filter can only be configured and activated from the PC. An active equalizer or filter is indicated in the channel path by an LED (EQU). The frequency response can be displayed graphically on the screen.

#### 2.2.4 Channel Mode

Channel 1 is exclusively assigned for mono (MIC1). Channels 2 + 3 have a *Mono/stereo* button; the current condition is indicated through the key lamp.

The PC software allows the user to configure the processing of left and right channel; the current setting is displayed through the L and R LEDs:













LED L	LED R	Mode
off	off	normal
on	off	left channel only
off	on	right channel only
on	on	left right swapped

Panning is available in *mono* mode, in stereo mode balance control is available instead. Pressing the PAN button activates the pan function and the jog-wheel and the five buttons arranged above then function temporarily for panorama / balance settings. When active the pan function is indicated by a blinking LED and the current pan position is indicated by means of the respective red LEDs in the five buttons above the jog-wheel. Pressing the PAN button once more saves the current setting which is indicated by the pan LED remaining lit. Pressing the pan button again deactivates the panorama / balance setting.

When changing the source the basic configuration will be activated automatically, in order to avoid problems (e.g. when switching from microphone mode in mono to stereo line sources).

#### 2.2.5 Inserts / effects

An insert or effect setting is available for the input channels. The selection is made from the PC software.

• Insert mode:

For any one of the 3 channels insert mode can be activated from the PC. In this mode the signal coming from the channel, prior to the fader, is output via the INSERT SEND output, and the returning signal from the INSERT RETURN input is fed into the mixing stage. This setting is indicated by the INSERT LED in the input section.

Effect mode:

Alternatively, selecting the effect mode portions of all 3 channel signals are mixed to the INSERT SEND output. The proportions can be controlled via the PC (effect control). The returning signal from the INSERT RETURN input is mixed with the sum signal. This setting is also indicated by means of the INSERT LED.

#### 2.2.6 Fader / level meter

All 3 channels have a fader which mixes the respective input signal to the sums. The mixing selection for the N-1 sums depends automatically on the selected input sources.

The current signal level is shown by means of an 8-level LED display and the additional clipping displays. The level display can be driven from the signal before or after the fader.

#### 2.2.7 Mute button and talk-back

The MUTE button can be used to mute either MIC1 or MIC2 temporarily.









The central talk-back buttons (TALK TEL or TALK ISDN) can be used to temporarily switch the MIC1 or MIC2 signals exclusively to the respective N-1 sum (command function).

To which microphone (MIC1 or MIC2) the selected function is applied can be configured from the PC software.

### 2.3 Summing busses

The system features 4 summing busses:

- main sum (stereo)
- N-1 sum for telephone (mono)
- N-1 sum for ISDN (stereo)
- Insert/effect sum (stereo)

The **main sum** (stereo) is mixed directly with all channel signals depending on the respective fader setting as well as with any INSERT RETURN input signal (in effect mode); a subsequent sum control is not provided. A 14-level LED display (including overload indicator) shows the current summing level.

The **N-1 sum (ISDN)** is mixed with all channel signals depending on the respective fader setting with the exception of any selected ISDN input signal. The TALK ISDN button can temporarily switch the MIC1 or MIC2 signal exclusively to this sum.

The **N-1 sum (TEL)** is also mixed with all channel signal depending on the respective fader setting with the exception of any selected TELEPHONE input signal. The TALK TEL button can temporarily switch the MIC1 or MIC2 signal exclusively to this sum.

Portions of all 3 input channels can be mixed to the **insert / effect sum**. These signal gains can only be set from the PC software.

By means of the LIM button the limiter function (as an alternative to being assigned to the channels) can be assigned to the sums (main, N-1 TEL and N-1 ISDN). To which sum the limiter function is applied can be configured from the PC software.

## 2.4 Outputs

There are 7 outputs available:

- 2 x MASTER, stereo, balanced (XLR + return signal to AWS via 15-pin Sub-D)
- 2 x MASTER, stereo, unbalanced (Cinch)
- 1 x N-1 ISDN, stereo, balanced (return signal to codec via 15-pin Sub-D)
- 1 x N-1 TEL, mono, balanced (return signal to hybrid via 15-pin Sub-D)
- 1 x INSERT SEND, stereo, balanced (15-pin Sub-D)

The level of the various outputs can be adjusted by means of trim pots. All outputs (except both asymmetrical master outputs) are electronically balanced.













#### 2.4.1 Monitor matrix

There are 3 outputs for monitoring:

- 2 x Headphones, stereo, unbalanced (6.3 mm stereo jack)
- 1 x Speakers, stereo, balanced (XLR)

The control pad allows the following sources to be selected: LINE1, LINE2, AV/ AUX, AWS/PCX, TELEFON, ISDN, DIG, MAIN , N-1 ISDN, N-1 TEL. The PC software allows the user to select all available sources for monitoring.

The **headphone output** has a SPLIT mode by which the selected source signal is sent to the left headphone channel and the main sum signal sent to the right headphone channel (both in mono). In order to alleviate tiredness resulting from extended headphone use a switchable stereo-to-binaural function is provided. A headphone output is available on the control panel and the interface unit.

The **loudspeaker output** can either be switched to the main sum signal ( button) or to follow the monitoring selection. In the case off internal red light condition the loudspeaker output is automatically muted. The  $\triangleleft$  CUT button allows for the loudspeaker output to be explicitly muted without having to make changes to the loudspeaker volume settings.

The volume level for the headphones and loudspeakers can be controlled independently of one another.

## 2.5 GPI / external level meters

For fader start, red light and other signaling 8 open-collector outputs are provided; the functional programming is performed via the PC software, mainly without any restrictions. A button is provided specifically for the control of an external telephone hybrid (take over function).

For any return signals 8 optically-decoupled inputs are provided, whose evaluation is also configurable via the PC.

Another output is provided for the connection of an external level meter for the summer signal.

The GPI signals and external level meter are fed out to two 15-pin sub-D connectors.

## 2.6 DigaStudio Pro

The following features are available in the Pro version of DigaStudio:

#### 2.6.1 Channel functions

The DigaStudio Pro offers a 4<sup>th</sup> mixing channel, which can only be activated and used via the respective PC software. Otherwise the capabilities of the 4<sup>th</sup> channel are identical to those of channels 2 and 3 (refer to *2.2 Channel*).













#### 2.6.2 Microphone inputs

In addition to the standard microphone inputs 2 additional ones are provided (MIC3, MIC4) which are identical to MIC1 and MIC2. These sources can only be selected by means of the PC software.

#### 2.6.3 Digital audio inputs

For digital signals in AES/EBU format 2 inputs are provided with XLR connectors. To avoid any connection problems the input signals are fed via input transformers and sampling-rate converters.

#### 2.6.4 Digital audio outputs

The main sum signal is available on 2 digital outputs, decoupled by means of output-transformers. The synchronization is performed either internally (48 kHz) or externally by means of a sampling-rate converter, which can be synchronized via a sync input (XLR jacks) with empty-frame AES/EBU.<sup>1</sup>

# **3 Edit Controller**

The Edit Controller functions are a subset of those of the D.A.V.I.D. Hardware Controller EdiDesk. For the controlling of editing software a jog wheel and a number of different function keys are provided.

By default the buttons are assigned the most import Edigas or Multitrack Editor functions:

- Jog wheel mode:
- Edit functions:
- Transport functions:
- Trim functions:
- General functions:

SCRUB / SKIP SET MARKER, MARK IN, MARK OUT, CUT INSIDE, CUT OUTSIDE, UNDO, REDO

PLAY / STOP, RECORD, FF, FREV, JUMP TO PREV MARK, JUMP TO NEXT MARK, PLAY CLIP LOOP FROM, LOOP TO COPY, PASTE, UP, DOWN



Jog wheel with edit function keys

<sup>1</sup> With external synchronization only digital output 1 is available.











Special function: TIME STAMP  $(\oplus)$  - allows the storing of the current time in the interface unit for later processing by the PC software. The time stamps can be printed out or converted to markers for the editing software (e.g. to find specific passages in a recording which was run in the background).

# 4 PC control

By connecting a PC to the interface / signal processing unit, any function can be controlled remotely by the PC software. Mainly, this is used for configuration purposes and for execution of more complex functions not available through the control pad (i.e. filters, insert/effect settings etc.). Also, user profiles can be saved and restored this way, as well as updates of operating or DSP software.

Some examples of functions available through the PC interface:

- Input sensitivity for each source
- Filter: on/off, filter parameter, graphical frequency display
- Limiter: limiter parameters
- Control of inserts/effects
- selection of L+R, L or R
- phase inversion for a channel
- · Saving and loading of user-profiles by means of the PC
- Configuration of GPIOs
- Configuration of key assignments
- Download and storing of the operating system software (non-volatile)

The connection to the PC is performed by means of a special protocol, based on the RS-422 interface. By using the supplied communication driver any applications (i.e. other manufacturer's editing software) can communicate with the DigaStudio.











GPI0       Inserts / Effects       Program Settings         Channel 1       Channel 2       Channel 3       Channel 4       Sensitivity       I/O Settings       Limiters       Key Assignment         Source :       Mic 1       Active       Multe       Multe       Multe       0       0       0         Mic 3       Mic 4       Oight 1       Odd       SkHz       Odd       0	GPID Channel 1 Channel 2 Source : C Mic 1 C Mic 2 C Mic 3 C Mic 4 C Digital 1	2 Channel 3 Channel 4 Equalizer F Active High Freq Gain © 5 kHz - O- © 10 kHz OdB	Effects Sensitivity 1/0 Channel Mute MUTE Channel Mode Phase Invert Left Ride	Program D Settings   Limiters	M Settings Key Assignement
Deamel 1       Deamel 2       Channel 3       Channel 4       Sensitivity       I/D Settings       Limiters       Key Assignment         Source :	Channel 1 Channel 2 Source : C Mic 1 C Mic 2 C Mic 3 C Mic 4 C Digital 1	2 Channel 3 Channel 4 Equalizer F Active High Freq Gain © 5 kHz	Channel Mute Channel Mute MUTE Channel Mode Phase Invert Left Ride	0 Settings   Limiters	Gain
Source :       Character         Mic 1       Active         Mic 3       Freq       Gain         Mic 4       StHz       Orannel Mule         Oligital 1       StHz       Orannel Mule         Oligital 1       Olde       Digital 2         Oligital 1       Olde       Orannel Mule         Oligital 1       Olde       Digital 2         Oligital 2       Mid       Teq         Oligital 2       Mid       Olde         Mid       Freq       Gain         Mid       Freq       Gain         Mid       Olde       Olde         Mid       Freq       Gain         Mid       Freq       Gain         Mid       Olde       Olde         Mid       Steneo       Olde         Mid       Olde       Olde         Mid       Olde       Olde         Mid       Steneo       Mono         Steneo       Mono       On/Off	Source : C Mic 1 C Mic 2 C Mic 3 C Mic 4 C Digital 1	Equalizer F Active High Freq Gain © 5 kHz © 10 kHz OdB	Channel Mute MUTE Channel Mode Phase Invert Left Ride	Insert C On/Ott	Gain <u>10</u> - <u>0</u> -
	Clipbard	Mid Freq Gain -0- -0- -0- -0- -0- -0- -0- -0- -0- -0	L/R Select C L-R C R-R C L-L C R-L Mode C Stereo C Mono	Limiter Con/Dif Balance CO- R MID R On/Dif	-10 

Screen shot of PC software (channel 2 selected)

# **5** Accessories

Standard accessories are:

- Power cable
- Connecting cable interface unit control pad
- RS-422 cable incl. RS-232/422 adapter to be inserted into the PC
- Communication driver for the PC
- PC software for the configuration and control of various functions

Optional extras:

- Button labels (input selection, preview matrix, function buttons)
- Audio cable for direct connection DigaStudio PCX card
- Gooseneck microphone (e.g. AKG C 580-1)













• Software for central configuration of any DigaStudio connected to a network

# **6 Technical Data**

110 ~ 220V / 50 Hz		
app. 30 W		
330 x 260 x 8 - 60 mm		
19", 2 HE x 365 mm		













Management Data Group

Landsberger Strasse 87 80339 Munich Munich

Tel: +49 89 540 139 - 0 Fax: +49 89 540 139 - 50

**Document information** 

Author: Andreas Hildebrand File:

Revision date: 17.03.03

\\pluto\daten\david\produkt\digastudio\appInote\appnotedigastudio\_e97.doc









